

▪ NETS Contactless Bank Card



▪ NETS FlashPay Card



▪ NETS QR App



▪ Credit Card Scheme




Terminal Logon [终端机登入]



Select
选择


Log On

NETS/NETS FlashPay Transaction



1. Key in the **amount** and press

输入购物总额, 然后按




2. Tap the card on the terminal / Insert card into the terminal

将卡闪在终端机上或将卡插入终端机


3. If terminal prompts for PIN, customer to enter the PIN on the terminal and press

请顾客将个人密码输入在键盘上, 然后按




4. Select **Yes** to print out the duplicate receipt

选择




打印收据副本

NETS QR Transaction [NETS QR 交易]



1. Key in the **amount** and press

输入购物总额, 然后按



2. Select

选择



3. Wait for **QR Code** to be displayed on the terminal screen

请等候 QR 码显示在终端机银幕



4. Customer to scan the QR Code

请顾客扫描 QR 码



5. Select to print out the duplicate receipt


选择

Yes

打印收据副本


Reprint NETS / NETS FlashPay Receipt [重印 NETS 或 NETS FlashPay 收据]

1. Press
按



4. Select
选择

DUPLICATE
RECEIPT



2. Select
选择



Admin



5. Select
选择

NETS

or
或

NFP



3. Select
选择



NETS & NETS FlashPay Settlement



1. Press
按



2. Select
选择 Admin



3. Select
选择




4. Select
选择

Reprint NETS & NETS FlashPay Settlement



1. Press
按



2. Select
选择 Admin



3. Select
选择




4. Select
选择




5. Select
选择

Sale Transaction




1. Key in the **amount** and press

输入购物总额, 然后按



2. Tap the card on the terminal / Insert card into the terminal

将卡闪在终端机上或将卡插入终端机



3. Select

选择

Yes


to print out the duplicate receipt

打印收据副本


Void Transaction




1. Press
按





2. Select
选择




3. Select
选择



4. Select
选择



5. Enter **Password** and press
输入密码，然后按



6. Enter **Invoice number** and press
输入Invoice number，然后按




7. Press
按
- to void amount
以取消交易数额




Detail Report / Summary Report




1. Press
按 




2. Select
选择 



3. Select
选择 



4. Select
选择 




5. Select
选择 
or
或 


Reprint Receipt




1. Press
按 




2. Select
选择 
UPOS



3. Select
选择 



4. Select
选择 




5. Select
选择
or
或 



Settlement



1. Press
按



2. Select
选择



3. Select
选择

